

CX-1B

DMX TESTER

【User Manual】



Lite-Puter Enterprise Co., Ltd.

www.liteputer.com.tw

sales@liteputer.com.tw

INDEX

1. CX-1B DMX TESTER LAYOUT

1-1	Main features.....	2
1-2	Technical specifications	2
1-3	Faceplate manual	3
1-4	Dimensions	4

2. CX-1B Operating manual

2-1	DMX OUT	5
2-2	AUTO FADE	8
2-3	DMX IN	10
2-4	OUT LEVEL SET	11
2-5	Hexadecimal 、 Percent 、 Decimal display setting up.....	12
2-6	LCD background light	13
2-7	Mode of sleeping	13
2-8	Synchronal signal output	14
2-9	Low power indication	15

VER : 1.0

1. LAYOUT


1.1 MAIN FEATURES

- LIGHT & HANDY, PORTABLE.
- AVAILABLE FOR TESTING SYNCHORNIZED SIGNAL DMX IN 、 DMX OUT 。
- Built-in battery, it can work for several hours continuously. (Charge it 5 hours , it can work 3 hours or waiting 100 hours)
- LCD background lighting economizes on power to extend battery life.
- Sleeping device : Stop working in 5 minutes running, it will be in the mode of sleeping to extend battery life.

1.2 TECHNICAL SPECIFICATIONS

- Power Supply : DC 12V / 1A
- DMX INPUT : DMX512
- DMX OUTPUT CHANNELS : 512 CHANNELS
- DMX SIGNAL CONNECTOR : XLR 5PIN (× 2) 、 PHONE JACK RJ11 (× 2)
- OUTSIDE DIMENSIONS : 100 (W) x 50 (H) x 133 (L) mm
- WEIGHT : 750 g

1.3 FACEPLATE MANUAL




1	LCD display	8	Hexadecimal / percent alternate button
2	Baterry chrage indicator	9	DMX signal output : XLR 5 PIN
3	External power indicator	10	DMX signal input / output : XLR 5 PIN
4	Level revolving button	11	Synchronal signal output connector
5	FUNCTION OPTION	12	Power supply input DC 12V/1A
6	LCD display contrast button	13	DMX signal output : PHONE JACK RJ11
7	LCD background light turn-on button	14	Power switch

2. CX-1B OPERATING MANUAL

2.1 DMX OUT

1.Single channel 、 successive multi-channels DMX OUT set-up

STEP-1 : Turn on Power to go to function DMX OUT . Or you can press button **DMX OUT 1** in other function mode to go to DMX OUT , LCD will display :



STEP-2 : If you need to change the level of current channel , you can push the revolving button to make adjustment . (Up goes to level increase , down goes to level decrease)



STEP-3 : If you would like to change the channel , press button **◀** or **▶** ; For example , you would like to change to CH002 , press button **▶** , LCD will display :



CH002 will output 10%

STEP-4 : If you need to control successive multi-channels in the same time, you choose initial channel you require then press button **—** , LCD display :



CH002 、 CH003 will output 10%

STEP-5 : At the same time you press button ◀ or ▶ , you can choose ending channel .You press button ▶ again , LCD display :



CH002 、 CH003 、 CH004 will output 10% .

STEP-6 : You can also press button ◀ to reduce ending channel , when you press button ◀ , LCD display :



2. DMX OUT sending frequency set-up

2 kinds of sending frequency are available for CX-1B , they are 20/S 、 40/S respectively :
 1 、 20/S is the DMX 512 signal sending 20 times of every second , it is for normal dimmer pack to test data receiving .
 2 、 40/S is the DMX 512 signal sending 40 times of every second , it is for dimmer pack to test high speed data receiving .



DMX sending frequency is 20/S



DMX sending frequency is 40/S

STEP-1 : In the mode of 20/S , press button **DMX OUT 1** to go to function AUTO FADE (refer to 2.2) , then press button **DMX OUT 1** again to go back to the function of DMX OUT , but at the same time you will find that LCD display :



DMX sending frequency is 40/S

STEP-2 : In the same way , in the mode of 40/S , press continuously button **DMX OUT 1** twice to go to function of 20/S DMX OUT .

3. In the mode of DMX OUT , display of DMX IN

The picture below shows the positions of communication outlets :



In the mode of DMX OUT and AUTO FADE , the socket of DMX OUT continuously send out DMX 512 signal . The socket of DMX IN / OUT will also send out DMX OUT signal when no other DMX signal input , once it suspects DMX 512 signal of the socket coming from other controllers , it will be automatically defined as DMX IN to receive controller's signal .

STEP-1 : In the mod of DMX OUT , DMX IN / OUT socket receives DMX signal , LCD displays :



The upper row of LCD displays receiving DMX signal from CH001~CH004 , the level is 69% 、 95% 、 40% , in the mean while LED on **DMX IN** is lighted , it means that now we have DMX IN signal input .

STEP-2 : It is also available to test signal cable is working well or not . Insert the one side of the signal cable into DMX OUT socket of CX-1B , the other side is inserted into DMX IN / OUT socket of CX-1B , as picture below :



STEP-3 : The LCD display as below , the lower row is DMX OUT signal , the upper row is DMX IN signal . If the signal cable is normal , the level of DMX OUT and DMX IN will be equal .




If no DMX signal is received , or the level of receiving is different from level of sending , it means that signal cable is abnormal .

2.2 AUTO FADE

1. Signal channel 、 successive multi-channels AUTO FADE set-up

STEP-1 : In the mode of DMX OUT , press button **DMX OUT 1** to go into function of AUTO FADE , LCD will displays :



STEP-2 : You'll find the current channel level (CH001) is flowing (0% → FL → 0%) .



STEP-3 : The speed of AUTO FADE can be changed by LEVEL adjustment . Push up to expedite AUTO FADE speed , push down to reduce AUTO FADE speed .

STEP-4 : If you wish to amend channel , press button ◀ or ▶ . While you press button ▶ , LCD displays :



CH002 will proceed with AUTO FADE .

STEP-5 : If you require successive multi-channels to proceed with AUTO FADE , you choose initial channel first then press button − , LCD displays :



While AUTO FADE is operating as below :

CH002 : 0% → 100% → 0% → CH003 : 0% → 100% → 0% → CH002 : 0% → 100% → 0%

STEP-6 : Press button ◀ or ▶ , you can change ending channel . When you press button ▶ LCD displays :



When you press button ▶ , the ending channels are increasing .

STEP-7 : In the same way , while you press button ◀ to decrease ending channels . When you press button ◀ , LCD displays :



2. AUTO FADE sending frequency setup

※ AUTO FADE has 2 kinds of sending frequency , 20/S & 40/S .



DMX sending frequency 20/S



DMX sending frequency 40/S

※ Press continuously button **DMX OUT 1** , you can switch between (DMX OUT 20/S) 、 (AUTO FADE 20/S) 、 (DMX OUT 40/S) and (AUTO FADE 40/S) .


3. DMX IN display in the mode of AUTO FADE

STEP-1 : In the mode of AUTO FADE , when DMX IN / OUT socket receive other DMX signal , the way of LCD display is the same as in the mode of DMX OUT :



2.3 DMX IN

STEP-1 : Press button **DMX IN** to go to the function DMX IN , LCD displays :



START CODE : It is the DMX IN start code level which is received .

DMX IN times of receiving : It shows how many times DMX IN signal are received .
When the numbers of DMX IN receiving are higher than 99 , it will be switch to received DMX IN frequency .

% / H / D : It shows the current unit is **Hexadecimal** or **Percent** or **Decimal** .

C001 : It means that the current DMX IN initial channel .

※ While the channel receives DMX IN signal , LED of button **DMX IN** will be lighted .

STEP-2 : If you would like to change the current initial channel , press button **◀** or When you press button **▶** , LCD display :




※ In the mode of DMX IN , CX-1B will remain previous status if you move the input DMX signal away , you can press button **DMX IN** again to clean the received DMX IN memories , LCD displays :



2.4 OUT LEVEL SET

Basically OUT LEVEL SET and DMX OUT have the same function , they output a DMX 512 signal to control the dimming pack . The only one difference is that OUT LEVEL SET can set different output level for individual channel from CH001 to CH512 , but DMX OUT can only set the same output level for successive channels .

STEP-1 : Press button **DMX OUT 2** to go to function OUT LEVEL SET , LCD display :



20/S : DMX OUT sending frequency (this remains original DMX OUT frequency) .
% / H / D : It shows the current unit is **Hexadecimal** or **Percent** or **Decimal** .
C001 : It means the current initial channel of OUT LEVEL .

STEP-2 : You will find 00 in the first place is shinning , it means the current controllable channel .



STEP-3 : Push LEVEL revolving button to adjust output level .



For example , adjust LEVEL to be 37 , the DMX OUT signal of the first channel will output 37% .

STEP-4 : Press button ◀ or ▶ to adjust controllable channel. When you press button ▶ 3 times continuously , LCD displays :



You'll find that CH004 becomes the current controllable channel . To put LEVEL revolving button to change output level of the said channel .

STEP-5 : To press button ▶ again , LCD displays :



CH005 becomes the current controllable channel (You'll find that initial channel of OUT LEVEL becomes C002)

STEP-6 : You can clean the set levels of all channels the set-up by pressing and holding the button **DMX OUT 2** 2 seconds , after that LCD displays :



2.5 Hexadecimal 、 Percent 、 Decimal DISPLAY SETTING UP

STEP-1 : In the mode of DMX OUT , it shows as percent , LCD displays :



STEP-2 : Press button **H / %** to switch to Hexadecimal , LCD will display :



STEP-3 : Then press button **H / %** to switch from Hexadecimal to Decimal , LCD will display :



※ The way to set up the display of Decimal and Hexadecimal and Percent is the same in AUTO FADE 、DMX IN and OUT LEVEL SET .


2.6 LCD BACKGROUND LIGHTING

STEP-1 : Press button **LIGHT** to turn on the LCD background light .

STEP-2 : CX-1B will automatically turn off background light after it does not work in 10 seconds in order to enlarge battery life.

2.7 MODE OF SLEEPING

STEP-1 : To enlarge battery life , CX-1B will get into the mode of sleeping after it does not work in 5 minutes , LCD displays :




STEP-2 : Press button **DMX OUT** to wake up CX-1B , it will resume working.

STEP-3 : If you would like to turn off SLEEPING , to press and hold button **LIGHT** then turn on the power . The function sleeping will be switched off , LCD displays :




2.8 SYNCHRONAL SIGNAL OUTPUT


CX-1B can output DMX IN 、DMX OUT synchronal signal to proceeding observation by Wave display .



STEP-1 : When you would like to observe DMX OUT signal , you can use wave display to measure SYNC of TO SCOPE (synchronal signal measurement connector) and TX ground (please refer to picture below) .




STEP-2 : For example , CX-1B sent signal CH001 = 42H DMX IN , you can use wave Display to measure from SYNC of TO SCOPE (synchronal signal connector) to TX ground , you can see the wave as below , CH-00 in red circle is the DMX wave of TX ground , CH-01 in red circle is the synchronal signal wave of SYNC .



2.9 Low power indication

STEP-1 : When the battery of CX-1B is in low power , the first line of LCD will switch between normal function and “BATTER LOW” , it displays in the mode of DMX OUT :



STEP-2 : Then you can charge CX-1B , otherwise CX-1B will be in the mode of low power sleeping after 1 minute , LCD displays :



STEP-3 : If you would like to operate CX-1B in low power , you can press button **DMX OUT1** to wake it up to be back to work . CX-1B will be in the mode of low power sleeping after 1 minute .